






TVman Media Center User Guide

Index

I.	Introduction-----	p.3-4
II.	User Guide	
◆	 PC Connection Guide -----	p.5-6
◆	 Android Connection Guide -----	p.7-10
◆	 iOS Connection Guide -----	p.11-14

TVman media center gives user the freedom to:

Share: Friends and family can now access (watch) your favorite videos and pictures without the hassle of sending them one-by-one.

File transfer: Peers can now upload & download files through TVman media center.

Memory extension: You can now use TVman SD card or USB HDD as additional storage space for your smart phone and tablet.





Samba Media Center Player


- TVman Samba media center feature is compatible with any available third party players for iOS and Android that supports Samba.
- User must refer to user manual of third party player for detailed instructions.
- The following Samba players mentioned are for demonstration purpose only.




PC Connection

Step 1: Connect PC to TVman WiFi or home router network


Step 2: Open Windows file explorer and enter \\noovo



Step 3: Select Share



Step 4: Select the movie, music, picture file that you wish to play.






Android Connection

Step 1: Install ES File Explorer




Step 2: Connect to TVman WiFi in your WiFi setting



Step 3: Open ES File Explorer and press on Fast Access icon




Step 4: Choose LAN under Network



Step 5: Press Scan




Step 6: Select TVman IP "10.88.88.88".
Or choose your router IP if you are in WLAN mode.



Step 7: Select Share



Step 8: Select the movie, music, picture file that you wish to play.






Step 1: Install File Explorer




Step 2: Connect to TVman WiFi in your WiFi setting




Step 3: Open File Explorer and select Linux/Unix



Step 4: Press the “+” icon




Step 5: Select Noovo or 10.88.88.88 under Network Neighborhood




Step 6: Select Guest



Step 7: Select Noovo or 10.88.88.88 under Shared



Step 8: Select Share



Step 9: Select the movie, music, picture file that you wish to play.

